

# MANUAL



## HEATABLE SOFT TOY

### HEATING INSTRUCTIONS

- Remove the filling from the toy and place in the microwave to heat.
- Heat only in microwave oven.  
Only adults should operate the microwave oven.
- Do not put the beanbag directly on a metal grill, instead put the beanbag on a plate before putting into the microwave.
- Before giving the product to your child, thoroughly knead the filling to make sure the heats is evenly distributed.
- Maximum Heating guidelines:  
600w - 800W = 2 minutes maximum  
850w - 1000W = 90 seconds maximum

### WARNINGS

- Temperature may increase after removal from the microwave oven.
- Only reheat when the element is at room temperature.
- This product can cause burns. Avoid prolonged direct contact with the skin.
- Do not place too close to the baby.
- Use this product only under parental supervision.

### COOLING INSTRUCTIONS

- Remove the beanbag from the toy and place a few hours in the freezer to cool.
- After cooling put the beanbag back in the soft toy.

### CLEANING INSTRUCTIONS

- Please follow the care instructions on the product label.



Pip the penguin



Paul the polar bear



Howy the husky



### ⚠ WARNING! SAFETY GUIDELINES

- IMPORTANT! keep for future reference.
- This ZAZU product is fully compliant with the EU, CA, AU, NZ, RU, CN & USA legislation.
- Please keep the packaging away from small children.
- The plush can be washed by hand and air dried, but remove the beanbag beforehand.
- Our microwaveable products have removeable inner bags, which contain flaxseeds and lavender leaves.

- Do not ingest contents.
- Inspect at regular intervals for damage.
- After each use store in a dry and cool place.
- Dispose of in normal household waste if worn or damaged.

Manufactured and distributed by ZAZU  
PO Box 299 | 3740 AG Baarn  
The Netherlands | info@zazu-kids.nl

